











G12(E)
Radio Receiver Assembly

G4(A), G5(B), G6(C), G23(D), G24(E), G27(F), G30(G), G31(H), G33(I)
Navigation Receiver Assembly












G12(E)
Radio Receiver Assembly

G4(A), G5(B), G6(C), G23(D), G24(E), G27(F), G30(G), G31(H), G33(I)
Navigation Receiver Assembly








G12(E)
Radio Receiver Assembly

G4(A), G5(B), G6(C), G23(D), G24(E), G27(F), G30(G), G31(H), G33(I)
Navigation Receiver Assembly

LG

LG

U6(A), U7(B), U8(C)
Headphone Terminal




G12(E)
Radio Receiver Assembly

G4(A), G5(B), G6(C), G23(D), G24(E), G27(F), G30(G), G31(H), G33(I)
Navigation Receiver Assembly

LG

LG

a17
Seat Back Display LH



G12(E)
Radio Receiver Assembly


G4(A), G5(B), G6(C), G23(D), G24(E), G27(F), G30(G), G31(H), G33(I)
Navigation Receiver Assembly

LG

LG

a17
Seat Back Display LH

Z21
Seat Back Display RH




G12(E)
Radio Receiver Assembly

G4(A), G5(B), G6(C), G23(D), G24(E), G27(F), G30(G), G31(H), G33(I)
Navigation Receiver Assembly

LG

Z21
Seat Back Display RH



G15(A), G16(B), P9(C)
Multi-Display Controller Sub-Assembly

(BAT)
15A
RAD
NO. 3

2

3

V

18

AF2

V

9

GF1

V

14

B

13

B

Y

14

B

+B

G21(B)
Junction Connector


SB

28

B


+B1

LG





G12(E)
Radio Receiver Assembly


G4(A), G5(B), G6(C), G23(D), G24(E), G27(F), G30(G), G31(H), G33(I)
Navigation Receiver Assembly




G15(A), G16(B), P9(C)
Multi-Display Controller Sub-Assembly









*10 : 15 Speaker
*11 : 12 Speaker



A 43
Black




A 44
Black




A 49
Black




D 1
Black




D 8
Gray




D 41
Black




F 13
Black




F 14
White




F 15
Black




F 16
Black




F 39
White




F 40
Black




F 54
Black




F 63
Black




F 64
Black




F 65
White




F 66
White




F 70
Blue



F 71
Blue




F 82
White




F 91
White




F 92
White



F 93
White




F 94
White




F 96
Blue




G 2
White




G 4
White




G 5
White




G 6
White




G 8
White




G 12
White




G 13
White




G 14
White




G 15
White




G 16
White




G 17
White




G 20
White




G 21
White




G 22
White




G 23
Black




G 24
White



G 25
White




G 27
Black



G 28
Blue



G 30
White



G 31
Gray




G 32
Gray




G 33
White




G 34
White




G 35
Gray



H 1
White




H 2
White




I 3
White



I 5
White




I 6
White




J 2
White




J 4
White



J 6
White




K 1
White




K 4
White




L 1
White




L 4
White




O 15
White




O 16
White



O 17
White




O 18
White




O 24

White




O 31

White




P 9

White




P 22

White




P 30

White




T 10

White




U 1

White




U 6

White




U 7

White




U 8

Gray




U 9

White




U 11

Black




U 12

Brown




Z 21

White




a 17

White




z 5

White




2A


White





2D
White





2F
White





AF2
Black





AF5
Blue




AF8
Blue




AF10
Black







HF2
Blue




IF2
White




JF1
White




KO1
White




LP1
White




OF2
Black




OF3
Gray




OG1
Black




OG2
Gray




OG3
White




OP2
White




OP3
Blue




OZ3
White




PF3
Blue




Pa2
White




TG2
Gray



UF1
White



UG1
Gray



UG2
White

