

1. Repair Wire Harness

Print
[C] Hint Close

[D]

Repair Wire Harness

Male Female	Part No. of Connector	Terminal Type	Sealing Ability	Part No. of Repair Wire		More info.
				160mm Type	500mm Type	
Female	90980-10845	2.3 II	Sealed	82998-12440 82998-12460(Au)	82998-12590 82998-12800	detail
		2.3 II			82998-24400 82998-24410	detail

[A]
[B]

[A] Repair Wire Harness

The Repair Wire Harness data is displayed.

[B] Detail

Click this button to access the detailed repair wire harness data.

[C] Hint

Click this button to access the Repair Wire Harness Introduction and Terminal and Connector Repair.

[D] Close

Click this button to close the window.

Note that you cannot click any buttons or enter any numbers outside this window while it is being displayed.

2. Detail

Print
[C] Hint Close

[D]


Terminal Type

Male / Female

2.3 II (Waterproof Type)

Female

Repair Wire




A = 3.0mm
D = 2.6mm
E = 2.00
1.25"

P/N:	160mm	82998-12440 82998-12460(Au)
	500mm	82998-12590 82998-12800

Sealing


Hole Plug



P/N: 90980-09152


Sleeve

Large (Yellow)




P/N: 82999-12030

Medium (Blue)



P/N: 82999-12020

Housing Cross Section



(Double Lock Type)
[Housing Lance]

[A] Detailed Repair Wire Harness Data

Supplementary information regarding repair wire harnesses is displayed.

HINT: This window is displayed only when the detailed repair wire harness data is available.

[B] Repair Wire Description

The following symbols are used on the screen.

A	Terminal width
B	Terminal diameter

C	Terminal guide width
D	Wire outside diameter
E	Nominal size of wire
*	Gold plated (Gilded)

[C] Hint

Click this button to access the Repair Wire Harness Introduction and Terminal and Connector Repair.

[D] Close

Click this button to close the window.

Note that you cannot click any buttons or enter any numbers outside this window while it is being displayed.