


Position of Parts in Instrument Panel <LHD>



- C 1 Driving Support ECU Assembly
- H 1 Meter Mirror Sub-Assembly
- H 2 Front No. 4 Speaker Assembly
- H 3 Automatic Light Control Sensor
- O 1 Certification ECU Assembly
- O 8 Airbag Sensor Assembly
- O 9 Front Indoor Electrical Key Oscillator
- P 9 Multi-Display Controller Sub-Assembly
- P 10 Airbag Sensor Assembly
- S 1 Oxygen Sensor (Bank 1 Sensor 2)
- S 2 Water Temperature Switch
- U 1 No. 1 Stereo Jack Adapter Assembly
- U 2 Power Point Socket Assembly (No. 1)
- U 3 Power Point Socket Assembly (No. 2)
- U 5 Console Box Illumination Light Assembly
- U 6 Headphone Terminal
- U 7 Headphone Terminal
- U 8 Headphone Terminal
- U 9 Multi-Media Interface ECU
- U 10 Multi-Media Interface ECU
- U 11 No. 1 Stereo Jack Adapter Assembly
- U 12 Multi-Media Interface ECU

Position of Parts in Instrument Panel <LHD>

