
















06-60 维修工具

转向系 SST 06-60-1

转向系 SST

id066000800100

49 1232 670B 动力转向装置计 量器套件 	49 H002 671 适配器 	49 G032 3A4A 动力转向装置计 量器转接器套件 
49 T028 3A0 球笼万向节拉拔 器装置 	49 B032 317 轴承和油封拆卸 工具 	49 F032 303 手柄 
49 N032 303 拆卸工具 	49 T028 301 防尘套安装用工 具 	49 D032 316 量角器 
49 0180 510B 预加应力 测量 连接 	49 G032 317 软管 	49 G032 319 适配器 
49 G033 106 固定器 	49 KKV4 81054A 扳手 	49 F017 1A0 通用扳手 
49 H032 338 铰接轴 	49 F032 301 动力转向油泵吊 架 	49 G033 102 手柄 