



燃油和排放系统

专用工具


基准号	工具号码	说明	数量
①	07LAA-PT50101	O2 传感器套筒扳手 22 × 90 升	1
②	07NAJ-P070100	机油压力表附件	1
③	07YAJ-0010610	组合仪表组件	1
④	07ZAJ-S5A0101	燃油压力表组件	1
⑤	07ZAJ-S5A0200	机油压力软管	1
⑥	07ZAJ-S7C0100	燃油软管附件	1
⑦	07ZAJ-S7C0200	燃油接头附件	1
⑧	07406-0070002	低压仪表	1
⑨	07406-0040004	燃油压力表	1
⑩	07410-5790503	管接头适配器	1
⑪	07AAA-S0XA100	燃油传感器扳手	1




①




②




③




④




⑤



⑥




⑦




⑧



⑨



⑩



⑪