


后差速器


专用工具

基准号	工具号码	说明	数量
①	070AD-STK0110	油封拆装器 A	1
②	070AD-STK0120	油封拆装器 B	1
③	070AD-STK0130	油封拆装器 C	1
④	070AJ-SJAR130*	螺母, 14 × 1.5 毫米	5
⑤	070AJ-SJAR112*	适配器, 扭矩扳手	1
⑥	07SAZ-001000A	背面探针组件	2
⑦	07XAB-0010101	结合法兰固定器	1
⑧	07AAD-S3VA100	驱动轴拆卸工具	1
⑨	07747-0010100	叉密封件拆装工具配重块	1


* 适配器部件, 扭矩扳手组件 070AJ-SJAR102。




①




②




③




④




⑤




⑥



⑦



⑧



⑨