




保护


专用工具

| 基准号             | 工具编号          | 说明             | 数量 |
|-----------------|---------------|----------------|----|
| ① <sup>*1</sup> | 07HAZ-SG00500 | 展开工具           | 1  |
| ②               | 07PAZ-0010100 | SCS 维修连接器      | 1  |
| ③               | 07SAZ-TB4011A | SRS 充气装置模拟器    | 1  |
| ④ <sup>*2</sup> | 07TAZ-001020A | 背部探针适配器, 17 毫米 | 2  |
| ⑤               | 07XAZ-S1A0200 | SRS 模拟器引线 E    | 1  |
| ⑥               | 07XAZ-SZ30100 | SRS 模拟器引线 F    | 1  |
| ⑦               | 07YAZ-S3A0100 | SRS 模拟器引线 H    | 1  |
| ⑧               | 070AZ-SNA0300 | SRS 模拟器引线 L    | 1  |
| ⑨               | 070AZ-SNA0400 | SRS 模拟器引线 M    | 1  |
| ⑩               | 070AZ-SAA0100 | SRS 短路解除装置     | 2  |


\* 1: 包含在 SRS 工具组件 07MAZ-SM5000B 内  
\* 2: 使用背面探测组件 T/N 07SAZ-001000A 中的线束。




①




②




③




④




⑤



⑥



⑦



⑧



⑨



⑩

