



- \*1: 驾驶员侧仪表板下保险丝 / 继电器盒
- \*2: 乘客侧仪表板下保险丝 / 继电器盒
- \*3: 发动机盖下辅助保险丝 / 继电器盒

38-48 ° C]

38-48℃]  
[动器

[40-50 ° C]

60–70 °C]