



## 第二章 主要线束图


# 一、T11-3724010VP 前舱线束总成




## 二、T11-3724030VP 仪表线束总成




### 三、T11-3724050NR 室内线束总成




## 四、T11-3724090BG 后背门线束总成




## 五、T11-3724070ND 左前门线束总成




## 六、T11-3724080ND 右前门线束总成




## 七、T11-3724110ND 左后门线束总成




## 八、T11-3724120ND 右后门线束总成



## 九、T11-3724037BC 顶棚线束总成





## 十、T11-3724011VA 正极线束总成



## 十一、T11-3724012VA 负极线束总成

接电瓶负极夹



发动机搭铁  
G601



车身搭铁  
G602