




| 底板线束(3) |                                              | CV40-3                                                                                                                                                                     |  |
|---------|----------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| F16     | 助手席安全带拉紧器<br>- 2母/黑色(JST_040_02F_B_SQXW)     |                                                                                           |  |
|         | 1. L SRS控制模块(高电位)      2. Br SRS控制模块(低电位)    |                                                                                                                                                                            |  |
|         |                                              |                                                                                                                                                                            |  |
| F17     | 助手席窗帘式空气囊<br>- 2母/黑色(JST_040_02F_B_SQXW)     |                                                                                           |  |
|         | 1. G SRS控制模块(低电位)      2. W SRS控制模块(高电位)     |                                                                                                                                                                            |  |
|         |                                              |                                                                                                                                                                            |  |
| F18     | 助手席侧面空气囊<br>- 2母/黄色(KET_040WP_2F_Y_040III)   |                                                                                          |  |
|         | 1. O/B SRS控制模块(高电位)      2. P/B SRS控制模块(低电位) |                                                                                                                                                                            |  |
|         |                                              |                                                                                                                                                                            |  |
| F19     | 助手席侧面碰撞传感器<br>- 2母/黄色(AMP_MQS_02F_Y_A)       |                                                                                         |  |
|         | 1. Y SRS控制模块(低电位)      2. B SRS控制模块(高电位)     |                                                                                                                                                                            |  |
|         |                                              |                                                                                                                                                                            |  |
| F20     | 助手席座椅安全带扣环开关<br>- 2母/白色(KET_090III_02F_W_L)  | <br> |  |
|         | 1. L 智能接线盒 (IPS控制模块)      2. B 搭铁(GF02)      |                                                                                                                                                                            |  |
|         |                                              |                                                                                                                                                                            |  |
| F21     | 后左车门开关<br>- 2母/白色(KET_070_02F_W)             |                                                                                         |  |
|         | 1. B 搭铁(GF03)      2. Gr 智能接线盒 (IPS控制模块)     |                                                                                                                                                                            |  |
|         |                                              |                                                                                                                                                                            |  |
| F22     | 后右车门开关<br>- 2母/白色(KET_070_02F_W)             |                                                                                       |  |
|         | 1. B 搭铁(GF04)      2. O 智能接线盒 (IPS控制模块)      |                                                                                                                                                                            |  |
|         |                                              |                                                                                                                                                                            |  |