



电路图



连接器端子编号



端子号	说明	备注
1	-	
2	-	
3	ECU蓄电池端子	
4	-	
5	CAN高电位	
6	CAN低电位	
7	-	
8	-	
9	搭铁	
10	-	
11	-	
12	-	
13	-	
14	-	
15	-	
16	-	
17	-	

18	点火开关"ON"	
19	-	
20	-	