



部件索引(1)

CI-1

英文名称	中文名称	部件编号	电路图页码
A/C Control Module (Auto A/C)	空调控制器(自动空调)	M21-A / M21-B	(SD569-1) / (SD879-2) / (SD971-1) / (SD971-2) / (SD971-3) / (SD971-4)
A/C Pressure Transducer	空调压力传感器	E19	(SD313-7) / (SD313-12) / (SD313-22) / (SD971-4)
A/V & Navigation Head Unit (4.0)	音频/视频&导航控制器(4.0)	M15-4A / M15-4B / M15-4C	(SD969-1) / (SD969-2) / (SD969-3)
A/V & Navigation Head Unit (CDMA)	音频/视频&导航控制器(CDMA)	M15-C	(SD969-2) / (SD969-5)
A/V & Navigation Head Unit (GND)	音频/视频&导航控制器(搭铁)	M15-GND	(SD969-1) / (SD969-5)
A/V & Navigation Head Unit (GPS)	音频/视频&导航控制器(GPS)	M15-G	(SD969-2) / (SD969-5)
A/V & Navigation Head Unit (PIO)	音频/视频&导航控制器(PIO)	M15-PA / M15-PB / M15-PC	(SD969-5) / (SD969-6) / (SD969-7) / (SD969-8)
A/V & Navigation Head Unit (RADIO)(4.0)	音频/视频&导航控制器(收音机)(4.0)	M15-4R	(SD969-2)
A/V & Navigation Head Unit (RADIO)(PIO)	音频/视频&导航控制器(收音机)(PIO)	M15-PR	(SD969-6)
ABS Control Module	ABS控制模块	E02	(SD587-1) / (SD587-2) / (SD587-3) / (SD587-4)
Accel Pedal Position Sensor	加速踏板位置传感器	E18	(SD313-6) / (SD313-14) / (SD313-21)
Alternator	交流发电机	C106 / C206 / C306 / E111 / E121 / E131	(SD373-1) / (SD373-2) / (SD373-3)
Ambient Temperature Sensor	室外温度传感器	E81	(SD971-2)
AMP (JBL)	AMP(JBL)	F02-JA / F02-JB	(SD969-3) / (SD969-4)
ATM Shift Lever (A/T)	ATM变速杆(A/T)	F45-A	(SD450-1) / (SD450-3) / (SD452-1) / (SD954-5)
ATM Shift Lever (DCT)	ATM变速杆(DCT)	F45-B	(SD452-2) / (SD954-5)
ATM Shift Lever Indicator	ATM变速杆指示灯	F51	(SD450-2) / (SD450-4) / (SD450-8)
ATM Solenoid Valve	ATM电磁阀	C104 / C204	(SD450-1) / (SD450-3)
Audio	音响	M09-A / M09-B / M09-C / M09-G / M09-R	(SD961-1) / (SD961-2) / (SD961-3)
Audio Remote Control Switch (LH)	音响远程控制开关(左)	M72	(SD961-1) / (SD969-1) / (SD969-5)
Auto Defogger Actuator	自动除湿执行器	M33	(SD879-2) / (SD971-3)
Auto Defogger Sensor	自动除湿传感器	R12	(SD879-2) / (SD971-3)
Auto Head Lamp Leveling Device Module	自动大灯水平调整模块	F03	(SD922-2)
Auto Light & Photo Sensor (W/O JBL AMP)	自动灯光&光照度传感器(未配备JBL AMP)	M30-A	(SD814-1) / (SD951-1) / (SD971-3)
Auto Light & Photo Sensor (With JBL AMP)	自动灯光&光照度传感器(配备JBL AMP)	M30-B	(SD951-1) / (SD971-3)
AUX & USB Jack (Audio)	AUX&USB接口(音响)	M11	(SD961-2)
AUX & USB Jack (Navigation)	AUX&USB接口(导航)	M12	(SD969-3)
Battery Sensor	蓄电池传感器	E08	(SD313-4) / (SD313-14) / (SD313-19) / (SD373-1) / (SD373-2) / (SD373-3)
BCM	BCM	M02-A / M02-B / M02-C / M02-D	(SD952-1) / (SD952-2)
Blind Spot Detection Radar LH	后左侧方盲区监测雷达	R24	(SD957-9)
Blind Spot Detection Radar RH	后右侧方盲区监测雷达	R25	(SD957-9)
Blower Motor	鼓风机电机	M23	(SD971-1)
Blower Relay	鼓风机继电器	E39	(SD971-1)
Brake Booster Vacuum Pressure Sensor	制动助力器真空压力传感器	E09	(SD313-22)
Brake Fluid Level Sensor	制动油量传感器	E04	(SD587-1) / (SD588-1) / (SD588-5)
Burglar Alarm Horn	防盗警报喇叭	E16	(SD814-1)
Camshaft Position Sensor #1 (Intake)	凸轮轴位置传感器#1(进气)	C113-1 / C213-1 / C313-1	(SD313-5) / (SD313-12) / (SD313-20)
Camshaft Position Sensor #2 (Exhaust)	凸轮轴位置传感器#2(排气)	C113-2 / C213-2 / C313-2	(SD313-5) / (SD313-12) / (SD313-20)
Center Personal Lamp	中央私人灯	R11-C	(SD929-1)