



## 部件索引(7)

CI-7

|   | 英文名称                                        | 中文名称             | 部件编号                               | 电路图页码                                                                                                                                                                                                     |
|---|---------------------------------------------|------------------|------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| P | Passenger Seat Manual Switch (2WAY)         | 助手席座椅手动开关(2方向)   | S21-C                              | (SD880-6)                                                                                                                                                                                                 |
|   | Passenger Seat Manual Switch (8WAY)         | 助手席座椅手动开关(8方向)   | S21-B                              | (SD880-5)                                                                                                                                                                                                 |
|   | Passenger Seat Manual Switch (With Walk In) | 助手席座椅手动开关(配备上下车) | S21-D                              | (SD880-7)                                                                                                                                                                                                 |
|   | Passenger Seat Warmer                       | 助手席座椅加热器         | S29                                | (SD889-1)                                                                                                                                                                                                 |
|   | Passenger Side Air Bag                      | 助手席侧面空气囊         | F18                                | (SD569-2)                                                                                                                                                                                                 |
|   | Passenger Side Impact Pressure Sensor       | 助手席侧面压力式碰撞传感器    | D28                                | (SD569-3)                                                                                                                                                                                                 |
|   | Passenger Slide Motor                       | 助手席座椅滑动电机        | S27                                | (SD880-3) / (SD880-5) / (SD880-7)                                                                                                                                                                         |
|   | Passenger Smart Key Outside Handle          | 助手席智能钥匙外侧手柄      | D27                                | (SD929-2) / (SD954-5)                                                                                                                                                                                     |
|   | Passenger Temperature Actuator              | 助手席温度门执行器        | M28                                | (SD971-2)                                                                                                                                                                                                 |
|   | PCM                                         | PCM              | C100-A / C100-B<br>C200-A / C200-K | (SD313-3) / (SD313-4) / (SD313-5) / (SD313-6) / (SD313-7) / (SD313-8) / (SD313-11)<br>(SD313-12) / (SD313-14) / (SD313-15) / (SD313-18) / (SD313-19) / (SD313-20) / (SD313-21)<br>(SD313-22) / (SD313-23) |
|   | Power Outlet Relay                          | 电源插座继电器          | E42                                | (SD945-2)                                                                                                                                                                                                 |
|   | Power Outside Mirror Switch                 | 电动室外后视镜开关        | D12                                | (SD876-1) / (SD878-1)                                                                                                                                                                                     |
|   | Power Steering Sensor                       | 动力转向开关           | C232                               | (SD313-12)                                                                                                                                                                                                |
|   | Power Window Main Switch                    | 电动门窗主开关          | D02                                | (SD813-1) / (SD824-1) / (SD824-2) / (SD824-3) / (SD824-5) / (SD824-6)                                                                                                                                     |
| R | Purge Control Solenoid Valve                | 净化控制电磁阀          | C121 / C221 / C321                 | (SD313-5) / (SD313-11) / (SD313-20)                                                                                                                                                                       |
|   | Rail Pressure Sensor                        | 共轨压力传感器          | C140 / C340                        | (SD313-7) / (SD313-22)                                                                                                                                                                                    |
|   | Rain Sensor                                 | 雨传感器             | R03                                | (SD981-2)                                                                                                                                                                                                 |
|   | RCV Control Solenoid Valve                  | RCV控制电磁阀         | C127 / E21                         | (SD313-5) / (SD313-20)                                                                                                                                                                                    |
|   | Rear Combination Lamp (IN) LH               | 后左组合灯(内侧)        | F27                                | (SD924-2) / (SD926-1) / (SD926-2) / (SD927-2) / (SD928-2)                                                                                                                                                 |
|   | Rear Combination Lamp (IN) RH               | 后右组合灯(内侧)        | F28                                | (SD924-2) / (SD926-1) / (SD926-2) / (SD927-2) / (SD928-2)                                                                                                                                                 |
|   | Rear Combination Lamp (OUT) LH              | 后左组合灯(外侧)        | F29                                | (SD925-2) / (SD927-2) / (SD928-2)                                                                                                                                                                         |
|   | Rear Combination Lamp (OUT) RH              | 后右组合灯(外侧)        | F30                                | (SD925-2) / (SD927-2) / (SD928-2)                                                                                                                                                                         |
|   | Rear Defogger (+)                           | 后除霜器(+)          | F32                                | (SD879-1)                                                                                                                                                                                                 |
|   | Rear Door Lock Actuator LH                  | 后左门锁执行器          | D41                                | (SD813-2) / (SD814-2) / (SD929-3)                                                                                                                                                                         |
|   | Rear Door Lock Actuator RH                  | 后右门锁执行器          | D51                                | (SD813-2) / (SD814-2) / (SD929-3)                                                                                                                                                                         |
|   | Rear Door Speaker LH (JBL)                  | 后左车门扬声器(JBL)     | D43-J                              | (SD969-4)                                                                                                                                                                                                 |
|   | Rear Door Speaker LH (W/O AMP)              | 后左车门扬声器(未配备AMP)  | D43-S                              | (SD961-3) / (SD969-8)                                                                                                                                                                                     |
|   | Rear Door Speaker RH (JBL)                  | 后右车门扬声器(JBL)     | D53-J                              | (SD969-4)                                                                                                                                                                                                 |
|   | Rear Door Speaker RH (W/O AMP)              | 后右车门扬声器(未配备AMP)  | D53-S                              | (SD961-3) / (SD969-8)                                                                                                                                                                                     |
|   | Rear Heated Relay                           | 后加热器继电器          | E46                                | (SD879-1)                                                                                                                                                                                                 |
|   | Rear Height Sensor                          | 后高度传感器           | F38                                | (SD922-3)                                                                                                                                                                                                 |
|   | Rear Parking Assist Sensor LH               | 后左驻车辅助传感器        | R21-L                              | (SD957-3)                                                                                                                                                                                                 |
|   | Rear Parking Assist Sensor LH (Center)      | 后左驻车辅助传感器(中央)    | R21-CL                             | (SD957-3)                                                                                                                                                                                                 |
|   | Rear Parking Assist Sensor RH               | 后右驻车辅助传感器        | R21-R                              | (SD957-3)                                                                                                                                                                                                 |
|   | Rear Parking Assist Sensor RH (Center)      | 后右驻车辅助传感器(中央)    | R21-CR                             | (SD957-3)                                                                                                                                                                                                 |
|   | Rear Personal Lamp LH                       | 后左私人灯            | R11-L                              | (SD929-1)                                                                                                                                                                                                 |
|   | Rear Personal Lamp RH                       | 后右私人灯            | R11-R                              | (SD929-1)                                                                                                                                                                                                 |