


电路图


[电路图]




[连接信息]

端子	连接到	功能
1	4WD ECU (8)	油压电机 (+)
2	4WD ECU (7)	油压电机 (-)
6	搭铁	-

[线束连接器]



[油压电机]



[4WD ECU]