


控制线束(G4NB/G4NA: NU 1.8L/2.0L MPI)(10)			CV32-10
C225	歧管绝对压力传感器 - 4母/黑色(AMP_JPT_04F_B_BOSCH)		 
1. Gr	ECM/PCM(信号)	3. G	ECM/PCM(空气温度输入)
2. L/O	ECM/PCM(电源)	4. B	ECM/PCM(搭铁)
C228	空调压缩机(手动空调-未配备外部控制压缩机) - 1母/黑色(KUM_NMWP_01F_B_A)		
1. O	EMS盒(空调压缩机继电器)		
C237	倒车灯开关(M/T) - 2母/黑色(AMP_EJWP_02F_B)		
1. L/O	发动机室保险丝&继电器盒(保险丝-F9)	2. Gr/B	倒车灯: 后组合灯(内侧)-左/右、 音响、电镜后视镜、 智能接线盒(IPS控制模块-R'信号)
C238	起动机电磁开关 - 1母/黑色(KET_250WP_01F_B)		
1. B	发动机室保险丝&继电器盒(继电器5)		
C239	可变进气电磁阀 - 2母/黑色(AMP_EJWP_02F_B)		
1. O	EMS盒(保险丝-F39)	2. Gr	ECM/PCM(VIS控制)
C242	车速传感器(M/T) - 3母/黑色(KUM_NMWP_03F_B)		
1. B	搭铁(GC201)	3. Y	车速信号:
2. P	发动机室保险丝&继电器盒(保险丝-F10)		仪表盘(速度输入)、 ECM、诊断连接器、 数字时钟、音响、 暖风/空调控制器、 智能钥匙控制模块