

控制线束(G4NB/G4NA: NU 1.8L/2.0L MPI)(6)

CV32-6

C207	电动空调压缩机 - 3母/黑色(KUM_NMWP_02F_B)		
1. L/B	暖风/空调控制器(ECV(-))	2. Br	暖风/空调控制器(ECV(+))

C211	发动机冷却水温度传感器 - 3母/黑色(KUM_62Z_03F_B_WTS)		
1. L/O	ECM/PCM(传感器搭铁)	3. Y	ECM/PCM(传感器信号)
2. -	-		

C213-1	凸轮轴位置传感器#1 - 3母/黑色(AMP_JPT_03F_B_S1)		
1. G/O	EMS盒(保险丝-F40)	3. L/O	ECM/PCM (CAM #1(进气)搭铁)
2. G	ECM/PCM(CAM #1(进气)信号)		

C213-2	凸轮轴位置传感器#2 - 3母/黑色(AMP_JPT_03F_B_S1)		
1. G/O	EMS盒(保险丝-F40)	3. Y	ECM/PCM (CAM #2(排气)搭铁)
2. W	ECM/PCM (CAM #2(排气)信号)		

C214	曲轴位置传感器 - 2母/黑色(AMP_JPT_02F_B_BSH2)		
1. G	ECM/PCM(搭铁)	2. O	ECM/PCM(信号)

C215	机油压力开关 - 1母/黑色(KUM_NMWP_01F_B)		
1. O	仪表盘(机油压力警告灯)		