

ECU 诊断信息

BCM、IPDM E/R 和 BCM

ECU 参考列表

INFOID:000000009066152

ECU		参考
ECM	参考值	- MR20DE (欧 4): EC-93, "欧 4: 参考值" - MR20DE (欧 5): EC-115, "欧 5: 参考值" - QR25DE: EC-1090, "参考值"
	失效 - 保护	- MR20DE (欧 4): EC-103, "欧 4: 失效 保护" - MR20DE (欧 5): EC-125, "欧 5: 失效 保护" - QR25DE: EC-1103, "失效 保护"
	DTC 检测优先表	- MR20DE (欧 4): EC-105, "欧 4: DTC 检测优先表" - MR20DE (欧 5): EC-127, "欧 5: DTC 检测优先表" - QR25DE: EC-1105, "DTC 检测优先表"
	DTC 索引	- MR20DE (欧 4): EC-106, "欧 4: DTC 索引" - MR20DE (欧 5): EC-128, "欧 5: DTC 索引" - QR25DE: EC-1106, "DTC 索引"
BCM	参考值	BCS-42, "参考值"
	失效 - 保护	BCS-68, "失效 - 保护"
	DTC 检测优先表	BCS-70, "DTC 检测优先表"
	DTC 索引	BCS-72, "DTC 索引"
IPDM E/R	参考值	PCS-14, "参考值"
	失效 - 保护	PCS-26, "失效 - 保护"
	DTC 索引	PCS-28, "DTC 索引"