

&lt;准备作业&gt;

**准备作业****准备作业****专用维修工具**

INFOID:0000000010495123

A

B

C

FAX

E

F

G

H

I

J

K



L

M

N

O

P

工具编号 工具名称	说明
KV40104000 轮毂锁紧螺母扳手 a: 85 mm (3.35 in) b: 65 mm (2.56 in)	拆下并安装轮毂锁紧螺母。   ZZA0802D
KV40107300 防尘罩束带卷曲工具	安装防尘罩束带
KV40107500 驱动轴附件	拆卸驱动轴
KV38107900 保护器 a: 直径 32 mm (1.26 in)	安装驱动轴   PDIA1183J





# 准备作业

[4WD]

<准备作业>

## 通用维修工具

INFOID:0000000010495124

工具名称	说明
驱动轴拔具	拆下驱动轴接头副总成
	 JPDIG0152ZZ
滑锤	拆卸驱动轴
	 ZZA0023D
球节拆卸器	拆下轮毂螺栓
	 NT146
凿子	拆卸和安装转向节和支柱总成 A: 16 – 32 mm (0.63 – 1.26 in) B: 10 mm (0.39 in) 或以上 C: 40 – 70 mm (1.57 – 2.76 in) L: 220 mm (7.87 in) 或以下 S: 14 mm (0.55 in) 或以上
	 JSEIA0915ZZ

## 润滑剂或 / 和密封剂

INFOID:0000000010501160

名称	说明
加注 NISSAN 正品润滑脂或同等产品	<ul style="list-style-type: none"> <li>接头副总成 (内侧)</li> <li>壳体 (内侧)</li> </ul>
涂抹密封膏 [维修零件 (440037S000)]	<ul style="list-style-type: none"> <li>接头副总成</li> </ul>