


连接器定位图

21.仪表线束-中控台(1)



1 FA049	前排电源插座 Cigar Lighter:Power	5 FA108	换挡机构 Shifter Mechanism
2 FA072	USB1 USB1	8 FA111	安全气囊控制模块-B SDM:B
3 FA143	USB2 USB2	7 FA041	接地 GND-13:R1
4 FA029	仪表板天线 PEPS Facia Antennna	8 FA032 /FA152 /FA154	接地 GND-12:R1/GND-12:R2/ GND-12:R3