





1b


1b






1d

1d




1e

1e



1f

1f




★1 : 端子编号可选排列

WI-40047

**1g**

**1g**






**OP** : 不需要按钮启动

**WP** : 需按钮启动

**\*1** : 不需要按钮启动 : Y/R

需按钮启动 : L

## 接头清单



接头清单

