

Table of Contents 1:3

Explanations & Abbreviations	6
How to use the wiring diagrams 1:2.....	7

Electrical distribution

Overview without Start/Stop function.....	9
Overview with Start/Stop function.....	10
Overview, Distribution box in engine compartment exc. 4-Cyl.....	11
Overview, Distribution box in engine compartment 4-Cyl.	12
Overview, Distribution box in passenger compartment	13
Overview, Distribution box in cargo compartment	14

Fuses

Distribution box in engine compartment F1 - F7	15
Distribution box in engine compartment F8 - F23	16
Distribution box in engine compartment F27 - F37	17
Distribution box in engine compartment F38	18
Distribution box in engine compartment F39 - F44	19
Central electronic module (CEM) F1 - F6	20
Central electronic module (CEM) F7 - F16	21
Central electronic module (CEM) F18 - F24	22
Distribution box in passenger compartment F1 - F20	23
Distribution box in passenger compartment F21 - F30	24
Distribution box in cold zone F1 - MF2	25
Distribution box in cargo compartment FA1 - FA11	26
Battery PF1 - PF2	27

Relays

Relays in the engine compartment	28
Relays in the engine compartment	29
Relays in passenger and cargo compartments	30

Ground connections

Overview	31
31/2 - 31/6	32
31/7	33
31/10	34
31/15	35
31/47 - 31/48	36
31/65 - 31/83	37
31/84 - 31/90	38
31/93 - 31/115	39
31/131 - 31/TRM	40

Control modules

Overview locations.....	41
Overview designations.....	42
Central electronic module (CEM) 1:3.....	43

Data communication high speed CAN exc. 4-Cyl. 1:2 ..	46
Data communication high speed CAN 4-Cyl. 1:2.....	48
Data communication intermediate speed CAN, LHD ...	50
Data communication intermediate speed CAN, RHD ..	51
Data communication Local CAN	52
Data communication Extended CAN	53
Data communication MOST	54
Data communication, LIN 1:3	55
Steering Wheel Module (SWM)	58

Group 26 Cooling system

Cooling fan 4-Cyl. Turbo 2.0l	59
Cooling fan 4-Cyl. Diesel 2.0l	60
Cooling fan 5-Cyl. Diesel	61
Cooling fan 6-Cyl.	62

Group 27 Engine controls

Cruise control 4-Cyl. Turbo	63
Cruise control 4-Cyl. Diesel	64
Cruise control 5-Cyl. Diesel	65
Cruise control 6-Cyl.	66
Start-/Stop function 4-Cyl. Turbo 2.0l	67
Start-/Stop function 4-Cyl. Diesel 2.0l	68
Start-/Stop function 5-Cyl. Diesel	69

Group 28 Ignition and control system

Engine management system, 5-Cyl. Diesel 1:3	70
Engine management system, 4-Cyl. Diesel 1:3	73
Engine management system, 4-Cyl. Turbo 2.0l 1:3	76
Engine management system 6-Cyl. 3.2l 1:2	79
Engine management system 6-Cyl. 3.2l PZEV 1:2	81
Engine management system, 6-Cyl. Turbo 1:2	83
Emission control 4-Cyl. Turbo	85
Emission control 6-Cyl. 3.2l PZEV	86
Emission control 6-Cyl. 3.2l	87
Emission control 6-Cyl. Turbo	88

Group 32 Alternator and voltage regulator

Power supply 4-Cyl. with Start/Stop	89
Power supply 5-Cyl. with Start/Stop	90
Power supply 5-Cyl. Diesel without Start/Stop	91
Power supply 6-Cyl.	92

Group 33 Starting system

Starting system 4-Cyl. Turbo 1:2	93
Starting system 4-Cyl. Diesel 1:2	95
Starting system 6-Cyl.	97
Starting system 5-Cyl. With Start/Stop 1:2	98
Starting system 5-Cyl. Without Start/Stop	100

Table of Contents 2:3

Group 35 Lighting

High and low beam, Halogen.....	101
High and low beam, Dual Xenon	102
Beam length adjustment, manual	103
Running/Parking light, Tail lights	104
Fog lights	105
Brake lights	106
Reversing lights	107
Follow-me-home lighting LHD	108
Follow-me-home lighting RHD	109
Active headlight	110
Interior lighting, LHD 1:3	111
Interior lighting, RHD 1:3	114
Lighting in door sill trims	117
Auxiliary lights.....	118

Group 36 Additional electrical equipment

Rain sensor.....	119
Direction indicator and hazard warning flashers LHD	120
Direction indicator and hazard warning flashers RHD	121
Wiper/Washer windshield	122
Washer headlights	123
Wiper/Washer rear window.....	124
Keyless vehicle 1:2.....	125
Horn	127
Anti-theft alarm	128
Parking assistance.....	129
Collision warning with power brake booster	130
Tire pressure monitoring system (TPMS)	131
Alcohol lock.....	132

Group 37 Wiring and fuses

Diagnostics system.....	133
Outlet 12 V	134
Cable harness towbar/tow hitch 4-pin	135
Cable harness towbar/tow hitch 7-pin.....	136
Cable harness towbar/tow hitch 13-pin.....	137
USB unit (AUU).....	138

Group 38 Instruments

Seat belt reminder	139
Driver information module.....	140

Group 39 Other

Audio High/Premium IAM 1:3	141
Audio High/Premium IHU 1:3.....	144
Audio 1:2.....	147
Cellular phone 1:2.....	149
DAB Radio	151
Multimedia monitor with DVD, Dual Screen RSE	152
TV receiver / TV control module	153
Bluetooth Handsfree IAM.....	154

Bluetooth Handsfree IHU	155
Navigation system & Traffic information, portable	156
Satellite radio	157
Parking camera.....	158
Wide angle camera front.....	159
Sensus Connected Touch.....	160

Group 43 Transmission

Automatic transmission AWF21	161
Automatic transmission AWF22.....	162
Transmission M66.....	163
Differential electronic module (DEM)	164

Group 55 Parking brake

Electric parking brake	165
------------------------------	-----

Group 59 Brake system

Brake control system & DSTC	166
-----------------------------------	-----

Group 64 Steering

Speed dependent power steering EHPAS	167
Speed dependent power steering EPAS	168

Group 76 Shock absorbers

Four-C	169
--------------	-----

Group 83 Doors and openings

Central locking front doors LHD	170
Central locking front doors RHD	171
Central locking rear doors	172
Central locking tailgate with POT	173
Central locking tailgate without POT	174
Signal receiver central locking	175
Central locking fuel filler flap	176
Power windows front doors LHD.....	177
Power windows front doors RHD	178
Power windows rear doors.....	179
Power sunroof.....	180

Group 84 Exterior decorative elements, etc.

Power door mirrors LHD	181
Power door mirrors RHD	182
Heated door mirrors LHD	183
Heated door mirrors RHD	184
Door mirrors with automatic dimming LHD	185
Door mirrors with automatic dimming RHD.....	186
Blind spot information system LHD 1:2	187
Blind spot information system RHD 1:2	189
Heated windshield LHD	191
Heated windshield RHD	192
Heated rear window	193

Table of Contents 3:3

Group 85 Interior equipment

Power driver's seat with memory function, LHD	194
Power driver's seat with memory function, RHD	195
Power passenger seat, LHD	196
Power passenger seat, RHD	197
Heated front seats with fans	198
Heated front seats without fans	199
Heated steering wheel	200
Heated rear seat	201
Adjustable lumbar support, driver LHD	202
Adjustable lumbar support, driver RHD	203
Adjustable lumbar support, passenger LHD	204
Adjustable lumbar support, passenger RHD	205

Group 87 Climate control system

Climate control system PTC-elements	206
Climate control system, 4-Cyl. Turbo 1:2	207
Climate control system, 4-Cyl. Diesel 1:2	209
Climate control system 5-Cyl. Diesel 1:2	211
Climate control system 6-Cyl. 1:2	213
Parking heater, auxiliary heater	215
Parking heater, remote start	216

Group 88 Internal equipment

Supplemental restraint system 1:2	217
Remote control opener garage door	219
Power folding headrest	220
Rear-view mirror with automatic dimming	221

Connectors..... 222

Branching points261

Cable harness routing in vehicle

Harness engine, 4-Cyl. Turbo	283
Harness engine, 4-Cyl. Diesel	283
Harness engine, 5-Cyl. Diesel	284
Harness engine, 6-Cyl. Turbo	284
Harness engine, 6-Cyl. 3,2L	285
Harness engine, 6-Cyl. 3,2L PZEV	285
Engine compartment harness, LHD	286
Engine compartment harness, RHD	286
Dashboard harness, LHD	287
Dashboard harness, RHD	288
Floor Harness, LHD	289
Floor Harness, RHD	290
Harness infotainment, LHD	291
Harness infotainment, RHD	292
Roof harness, LHD	293
Roof harness, RHD	294
Tunnel harness	295
Harness driver door, LHD	296
Harness driver door, RHD	296
Harness passenger door, LHD	297
Harness passenger door, RHD	297
Harness rear door, RHD	298
Harness rear door, LHD	298
Tailgate harness PAC	299
Tailgate harness without PHC	299
Harnesses bumper, front	300
Harnesses bumper, rear	300
Adapter harness, rear bumper	301
Adapter harness, heated windscreen	301

Component illustrations 302

Index 1:2 355

List of components 1:6 357