


底板线束 (5)


CV40-5

**F22 后右车门开关**  
- 2母/白色 (KET\_070\_02F\_W)



1. B 搭铁 (GF04)                      2. 0 智能接线盒 (IPS控制模块)

**F25 后左轮速传感器**  
- 2公/黑色 (KET\_09011WP\_02M\_B)




1. G ABS/ESP控制模块 (后左信号)                      2. 0 ABS/ESP控制模块 (后左电源)

**F26 后右轮速传感器**  
- 2公/黑色 (KET\_09011WP\_02M\_B)




1. Br ABS/ESP控制模块 (后右信号)                      2. W ABS/ESP控制模块 (后右电源)

**F27 后左组合灯 (内侧)**  
- 4母/白色 (KET\_62C\_04F\_W)




1. B 搭铁 (GF03)                      4. L 倒车灯:  
2. - - [A/T] 发动机室保险丝&继电器盒  
3. 0 EMS盒 (后右雾灯继电器) (保险丝-倒车灯)  
[M/T] 倒车灯开关

**F28 后右组合灯 (内侧)**  
- 4母/白色 (KET\_62C\_04F\_W)



1. B 搭铁 (GF04)                      4. L 倒车灯:  
2. - - [A/T] 发动机室保险丝&继电器盒  
3. Y EMS盒 (后右雾灯继电器) (保险丝-倒车灯)  
[M/T] 倒车灯开关

**F29 后左组合灯 (外侧)**  
- 6公/白色 (KET\_09011\_06M\_W)



1. L/0 转向灯: 智能接线盒 (ARISU 2 (4CH))                      4. G 制动灯继电器  
2. B 搭铁 (GF03)                      5. - -  
3. G/B 尾灯: 智能接线盒 (IPS (2CH))                      6. - -