

控制线束 (5)

CV30-5

CNG17 氧传感器 (下部)
- 4母/黑色 (KUM_NMWP_04F_B)



1. R PCM (信号) 3. W EMS盒 (保险丝 - F32)
2. L PCM (搭铁) 4. Y PCM (加热器)

CNG18-1 点火线圈 #1
- 2母/黑色 (MLX_090CIGAR_02F_B)



1. G PCM (1号气缸) 2. 0 EMS盒 (保险丝 - F30)

CNG18-2 点火线圈 #2
- 2母/黑色 (MLX_090CIGAR_02F_B)



1. G PCM (2号气缸) 2. B EMS盒 (保险丝 - F30)

CNG18-3 点火线圈 #3
- 2母/黑色 (MLX_090CIGAR_02F_B)



1. W PCM (3号气缸) 2. L EMS盒 (保险丝 - F30)

CNG18-4 点火线圈 #4
- 2母/黑色 (MLX_090CIGAR_02F_B)



1. R PCM (4号气缸) 2. Gr EMS盒 (保险丝 - F30)

CNG19 电容器
- 1母/黑色 (KET_58X_01F_B)



1. 0 EMS盒 (保险丝 - F30)