

前线束 (7)

CV20-7

E48 氧传感器 (上) (G4KH -W/O EURO 5)
- 4公/黑色 (KET_SWP_04M_B)



- | | | | |
|------|----------|------|-----------------|
| 1. P | PCM (搭铁) | 3. Y | PCM (加热器) |
| 2. W | PCM (信号) | 4. O | EMS盒 (保险丝-传感器1) |

E49 真空开关 (G4KH)
- 4母/N/A (CR04F086)



- | | | | |
|------|-----------|------|------------|
| 1. B | 搭铁 (GE05) | 2. G | 真空泵 (开关信号) |
|------|-----------|------|------------|