


ESP系统













This diagram illustrates the electrical architecture of an ABS system. Key components include:

- Solenoid Valves:** A row of eight solenoid valves labeled ESP, ICS, and ABS.
- Control Modules:** The ESP Control Module (ESP 控制模块) and ABS Pump Motor (ABS 泵电机).
- Sensors:** Wheel speed sensors (e.g., C02, C03, C04, C05, C06, C07, C08, C09, C10, C11, C12, C13, C14, C15, C16, C17, C18, C19, C20, C21, C22, C23, C24, C25, C26, C27, C28, C29, C30, C31, C32, C33, C34, C35, C36, C37, C38, C39, C40, C41, C42, C43, C44, C45, C46, C47, C48, C49, C50, C51, C52, C53, C54, C55, C56, C57, C58, C59, C60, C61, C62, C63, C64, C65, C66, C67, C68, C69, C70, C71, C72, C73, C74, C75, C76, C77, C78, C79, C80, C81, C82, C83, C84, C85, C86, C87, C88, C89, C90, C91, C92, C93, C94, C95, C96, C97, C98, C99, C100) and a pressure sensor (压力传感器).
- Wiring Harnesses:** Various harnesses are shown, including the main ABS harness and individual component harnesses.
- Connectors:** Numerous connectors are labeled, such as ECU, ABS, and various pin headers.

The diagram uses standard automotive symbols for solenoids, motors, sensors, and electrical connections. It also includes labels for different types of wires (e.g., power, ground, signal) and specific wire colors/codes.

ESP系统

C54/C154/C254  KET_25X01_04F_W	C60/C160/C260  AMP_MQSWP_04F_GR_1	C65/C165/C265  AMP_MQSWP_03F_GR_1	E02  KET_090WVP_03M_GR
E32  KET_090WVP_03M_GR	BLANK	E34  KET_DIAGN035_20F_B_CUP	BLANK
E39  AMP_ESP_41F_1_UNIT		F13  KUM_SSD_03F_B_B	BLANK
F28  KET_090M_03M_B_R	F29  KET_090M_03M_B_R	M14  KUM_CDR_05F_W	M26  KET_090M_06F_B