

控制线束

C01, C02, C03, C04	C09
C05	C10
C07, C08	C11, C12, C13
C14, C15, C16	C21
C18-1, C18-2, C19	C22
C20	C23