



部件



连接器(6端子)	编号	说明
	1	-
	2	搭铁
	3	电源(12V)
	4	ESCL- 启动(闭锁)
	5	ESCL- 开锁
	6	ESCL(COM)