

保险丝&继电器信息(4)

SD100-4

电路(后接线盒)

编号	(A)	符号	保险丝名称	电路保护
F51	30A		Trunk Lid	行李箱盖控制模块
F52	15A	P/DOOR RR RH	Rear Power Door RH	后右车门碰锁
F53	15A		Door Lock 2	助手席车门模块
F54	15A	P/DOOR RR LH	Rear Power Door LH	后左车门碰锁
F55	15A	³ SPARE	SPARE 3	备用保险丝
F56	10A	¹ SPARE	SPARE 1	备用保险丝
F57	25A		Passenger Power Seat	助手席电动座椅继电器
F58	10A		Fuel Lid	燃油加油口门开启继电器、仪表板开关
F59	15A	ECS	ECS	ECS模块
F60	10A		Door Lock 1	驾驶席车门模块
F61	15A	⁵ SPARE	SPARE 5	备用保险丝
F62	10A		Trunk Lid	行李箱盖继电器、电动行李箱盖模块蜂鸣器
F63	20A		Rear Seat Warmer RH	6:4类型:后右CCS模块, 长座椅类型:后右座椅加热器控制模块
F64	10A		Rear F/Lamp	后雾灯继电器
F65	25A	AMP	AMP	AMP
F66	20A		Rear Seat Warmer LH	6:4类型:后左CCS模块, 长座椅类型:后左座椅加热器控制模块
F67	30A		Passenger Power Window	驾驶席/助手席电动门窗模块、后右电动门窗模块
F68	20A	F/PUMP	Fuel Pump	燃油泵继电器
F69	40A	RR HTD	Rear Defogger	后除霜器继电器

※ 仅能使用规定规格保险丝和继电器