

线束连接(1)


CV90-1

CC01 控制线束至左喷嘴线束连接(G6DG/G6DH/G6DJ)

- 10母/黑色(AMP_060WP_10F_B)
- 控制线束



- 10公/ N/A
- 左喷嘴线束




CC02 控制线束至右喷嘴线束连接(G6DG/G6DH/G6DJ)

- 6母/黑色(AMP_060WP_6F_B)
- 控制线束



- 6公/ N/A
- 右喷嘴线束



CC03 控制线束至左点火线圈线束连接(G6DG/G6DH/G6DJ)

- 10母/黑色(AMP_060WP_10F_B)
- 控制线束



- 10公/ N/A
- 左点火线圈线束

