


蓄电池接线盒(1)

B/B-E 蓄电池接线盒
- 2母/白色(KUM_060_02F_W)
- 底板线束



1. - 2. R 保险丝-F3: 蓄电池传感器

B/B-RS 蓄电池接线盒
- 1母/白色(KET_58L_01F_W)
- 底板线束



1. R 保險絲-F1: 后接线块(保險絲-F51~F69)

B/B-ST 蓄电池接线盒
- 1母/黑色(KET_58L_01F_B)
- 蓄电池线束



1. B 保險絲-F2: 金屬芯塊(PCB #2保險絲-F57 ~ F67)