






图1

ECU-A(A)

1	2	3	4	5	6	7					
8	9	10	11	12	13	14	15	16	17		
18	19	20	21	22	23	24	25	26	27		
28	29	30	31	32						33	34

ECU-B(B)

1	2			3	4	5	6	7			
8	9	10	11	12	13	14	15	16	17	18	19
20	21	22	23			24	25			26	27
28	29	30	31			32	33			34	35

#1	#2	#3	#4	ISC	E02	E01
B-O	B-Y	B-W	B-L	B-R	Br	Br
IGT1 G-R	IGT2 G-B	IGT4 G-Y	PRG W-G	HP B-R	OCV+ R-Y	SLT+ W-L
VC R-W	THW R-L	VTA Y-R	IGF1 Y	OCV- R-B	G22 B	NE+ O
E2 Br	OIL Y-G					NE- W


KNKL W				HTL B-O		E1 Br	
NSW B-W	STA B-Y		ST B-R	S2 W-R	S1 W-G	SLU- GR	SLU+ G
ALT L		OXL1 W		VG P			NT+ R
EC Br	PSP Y			EVG V			NT- B


CA7136Z


ECU-4(D)


1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	17
18	19	20	21	22	23	X		24	25
26	27	X		28	29	X		30	31


+B B-R	MHSW L-B	BATT B-Y	TACH B	CF Y-R	FAN W-L
/	/	/	/	/	/
SIL	WFSE R	FC G	F/PS Y-B	/	/
LG-B	/	TC P-B	/	/	/
/	/	/	/	/	/














EFI ECU-A




EFI ECU-B




EFI ECU-C




ECT ECU-A



ECT ECU-B



ECT ECU-C





天津一汽

天津汽车工业销售有限公司

地址：天津市河西区围堤道156号 电话：022-88378888 传真：022-88373200 邮编：300201

1035-030701-1500