

* 1:w/ LEXUS Navigation System
* 2:w/o LEXUS Navigation System

G 1 Multi Information Display Assembly
G 2 Multi-Display Assembly
G 4 Navigation Receiver Assembly
G 5 Navigation Receiver Assembly
G 6 Navigation Receiver Assembly
G 7 Radio Receiver Assembly
G 8 Heater Control Panel (Radio Receiver Assembly)
G 9 Radio Receiver Assembly
G 10 Radio Receiver Assembly
G 11 Radio Receiver Assembly
G 12 Radio Receiver Assembly
G 13 Remote Operation Switch
G 14 Remote Operation Switch
G 15 Multi-Display Controller Sub-Assembly
G 16 Multi-Display Controller Sub-Assembly
G 17 Multi-Media Module Navigation Assembly
G 18 Power Back Door Main Switch
G 19 Glove Box Light Assembly
G 20 Junction Connector
G 21 Junction Connector
G 22 Junction Connector
G 23 Navigation Receiver Assembly
G 24 Navigation Receiver Assembly
G 25 Telematics Transceiver
G 26 Mayday Battery
G 28 Multi-Display Assembly
G 29 Navigation Receiver Assembly
G 30 Navigation Receiver Assembly
G 31 Navigation Receiver Assembly
G 32 Multi-Media Module Navigation Assembly
G 33 IEEE Connector
G 34 Telematics Transceiver

G 1
White



G 2
White



G 4
Black



G 5
White



G 6
White



G 7
White



G 8
White



G 9
White



G 10
White



G 11
Black

G 12
White



G 13
White



G 14
White



G 15
White



G 16
White



G 17
White



G 18
Blue



G 19
Gray

G 20
White



G 21
White



G 22
White



G 23
Black



G 24
White

G 25
White



G 26
White



G 28
Blue

G 29
White

G 30
White



G 31
Gray

G 32
Gray

G 33
Gray



G 34
White